
Internal jumper to enabled / disabled switch
1
2
3
4
5
6
7
8
9
10
Sub-D 15 pts
Female socket
9
1
15
8
To SEL 104-2 or SEL 110-2